

**Heller oven software upgrade to version 1.0.6.58 (windows 98SE):**

FOLLOW THE UNINSTALL INSTRUCTIONS ON SEPARATE SHEETS BEFORE SOFTWARE UPGRADE.

To install the new oven operating software unzip all files and copy on a CD or copy all files on a computer on which software need to update.

- Insert this CD into the CD-drive setup will start automatically. (If setup did not start automatically run the setup.exe program from CD).
- Left mouse click the "Next" button on the welcome window. Type in the user information "Name" and "Company", then left mouse click the "Next" button.
- For the English version of software choose the default setting "Typical", for other languages choose "Custom".
- Choose the default destination directory "C:\Heller" then left mouse click the "Next" button. If "Custom" setup was chosen select the application files box and a language version. Left mouse click the "Next" button. On the "Start coping files" window left mouse click the "Next" button. The setup program will start copying files. The setup program will fail to self register some files, and register other files, left mouse click on the default "OK" button in all cases.
- The program will create the paths for files, left mouse click "OK" and "YES" for these prompts. Left mouse click the "OK" button for all succeeded Regsvr32 windows.
- Choose the default to restart the computer now then left mouse click "Finish" from the setup complete window.

When the computer restarts run the "Heller System Setup Wizard" program inserting the parameters and options copied from the existing system. When all parameters are inserted left mouse click on the "Finish" button, and left mouse click on the "Save and Exit" button.

Copy the existing recipe files saved on the floppy disk before the new software installation to a "C:\Heller\Recipe Files" folder.

Note: If recipes were generated before version 1.0.5.6 they need to modify to make it compatible with current version. Contact Heller Service.